

MERLIN/ORION mount, Firmware update:

We have found the origin of the problem, and the problem can be repaired by updating the firmware of the motor controller.

The attached files can be used to update the firmware of the motors controller: (from 02.05.81 to 02.06.81):

« MCFirmwareLoader.zip » is a WinZip file, download and extract the file a new folder.
(MCFirmwareLoader.exe)

« MC001_V0206.zip » is a WinZip file, download and extract in the same folder.
(MC001_V0206.MCF)

If you have a "SynScan" hand controller (The hand controler to control Skywatcher's EQ6/HEQ5 and AzGoto mount like the Merlin "GoTo"):

Please read file "Goto mount procedure How to update the firmware of the motors controler.pdf".
It is used to connect the mount and a PC for updating the firmware.

If you do not have a SynScan hand controller, but can already connect a PC with the mount (Wired connection only !):

You can use the same MCFirmwareLoader.exe and the firmware file to update the firmware of the motors controller.

You don't need another software.

Good luck !

claudevh

January 9, 2010